

VIA MM3500


User Manual




Table of Contents

VIA MM3500 Motherboard Layout	3
Block Diagram	4
Chapter 1 Hardware Installation	5
1-1 Considerations Prior to Installation	5
1-2 Feature Summary	6
1-3 Installation of Memory	8
1-4 Installation of Expansion Cards	9
1-5 I/O Back Panel Introduction	10
1-6 Connectors Introduction	11
Chapter 2 BIOS Setup	21
Boot up screen	22
The Main Menu (For example: BIOS Ver. :f3d)	22
2-1 Standard CMOS Features	24
2-2 Advanced BIOS Features	26
2-3 Advanced Chipset Features	28
2-4 Integrated Peripherals	32
2-5 Power Management Setup	36
2-6 PC Health Status	39
2-7 Frequency / Voltage Control	40
2-8 Load Fail-Safe Defaults	41
2-9 Load Optimized Defaults	41
2-10 Set Supervisor/User Password	42
2-11 Save & Exit Setup	43
2-12 Exit Without Saving	43

VIA MM3500 Motherboard Layout



Block Diagram



Chapter 1 Hardware Installation

1-1 Considerations Prior to Installation

Preparing Your Computer

The motherboard contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Thus, prior to installation, please follow the instructions below:

1. Please turn off the computer and unplug its power cord.
2. When handling the motherboard, avoid touching any metal leads or connectors.
3. It is best to wear an electrostatic discharge (ESD) cuff when handling electronic components (CPU, RAM).
4. Prior to installing the electronic components, please have these items on top of an antistatic pad or within a electrostatic shielding container.
5. Please verify that the power supply is switched off before unplugging the power supply connector from the motherboard.

Installation Notices

1. Prior to installation, please do not remove the stickers on the motherboard. These stickers are required for warranty validation.
2. Prior to the installation of the motherboard or any hardware, please first carefully read the information in the provided manual.
3. Before using the product, please verify that all cables and power connectors are connected.
4. To prevent damage to the motherboard, please do not allow screws to come in contact with the motherboard circuit or its components.
5. Please make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing.
6. Please do not place the computer system on an uneven surface.
7. Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.
8. If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.

Instances of Non-Warranty

1. Damage due to natural disaster, accident or human cause.
2. Damage as a result of violating the conditions recommended in the user manual.
3. Damage due to improper installation.
4. Damage due to use of uncertified components.
5. Damage due to use exceeding the permitted parameters.

1-2 Feature Summary

Motherboard	◆ VIA MM3500
CPU	◆ VIA C7-D processor
Front Side Bus	◆ 400 MHz FSB
Chipset	◆ Northbridge: VIA CN896 ◆ Southbridge: VIA 8237A
LAN	◆ Onboard VIA 6107 chip (10/100 Mbit) /
Audio	◆ Realtek ALC883 CODEC ◆ Supports 2 / 4 / 6 / 8 channel audio ◆ SPDIF In / Out connection ◆ CD In connection
Storage	◆ VIA 8237A - 2 IDE connectors (IDE1, IDE2) with UDMA 33/ATA 66/ATA 100/ATA 133 support, allowing connection of 4 IDE devices - 2 SATA connectors (SATA0/SATA1), allowing connection of 2 SATA devices
O.S Support	◆ Microsoft Windows Vista/2000/XP
Memory	◆ 2 DDRII DIMM memory slots ◆ Supports 1.8V DDRII DIMMs
Expansion Slots	◆ 1 PCI slot ◆ 1 PCI-E x16 slot
Internal Connectors	◆ 1 24-pin ATX power connector ◆ 2 IDE connectors ◆ 2 SATA connectors ◆ 1 CPU fan connector ◆ 1 System fan connector ◆ 1 front panel connector ◆ 1 front audio connector ◆ 1 CD In connector ◆ 2 USB 2.0/1.1 connectors for additional 4 USB 2.0/1.1 ports by cables ◆ 1 SPDIF In / Out connector ◆ 2 COM port connectors (COMA / COMB) ◆ 1 WOL connector
Rear Panel I/O	◆ 1 PS/2 keyboard port ◆ 1 PS/2 mouse port ◆ 1 parallel port ◆ 1 VGA port ◆ 4 USB 2.0/1.1 ports ◆ 1 RJ-45 port ◆ 6 audio jacks (Line In / Line Out / MIC In/Surround Speaker Out (Rear Speaker Out)/Center/Subwoofer Speaker Out/Side Speaker Out)

I/O Control	◆ IT8716F-S chip
Hardware Monitor	◆ System voltage detection ◆ CPU / System temperature detection ◆ CPU / System fan speed detection
BIOS	◆ Use of licensed AWARD BIOS
Form Factor	◆ Micro ATX form factor; 19.0cm x 22.8cm

1-3 Installation of Memory



Before installing the memory modules, please comply with the following conditions:

1. Please make sure that the memory used is supported by the motherboard. It is recommended that memory of similar capacity, specifications and brand be used.
2. Before installing or removing memory modules, please make sure that the computer power is switched off to prevent hardware damage.
3. Memory modules have a foolproof insertion design. A memory module can be installed in only one direction. If you are unable to insert the module, please switch the direction.

The motherboard supports DDR II memory modules, whereby BIOS will automatically detect memory capacity and specifications. Memory modules are designed so that they can be inserted only in one direction. The memory capacity used can differ with each slot.





Fig.1

The DIMM socket has a notch, so the DIMM memory module can only fit in one direction. Insert the DIMM memory module vertically into the DIMM socket. Then push it down.




Fig.2

Close the plastic clip at both edges of the DIMM sockets to lock the DIMM module.


Reverse the installation steps when you wish to remove the DIMM module.

1-4 Installation of Expansion Cards

You can install your expansion card by following the steps outlined below:


1. Read the related expansion card's instruction document before install the expansion card into the computer.
2. Remove your computer's chassis cover, screws and slot bracket from the computer.
3. Press the expansion card firmly into expansion slot in motherboard.
4. Be sure the metal contacts on the card are indeed seated in the slot.
5. Replace the screw to secure the slot bracket of the expansion card.
6. Replace your computer's chassis cover.
7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
8. Install related driver from the operating system.

For example: Installing a PCI Express x16 VGA card:




CAUTION

Please carefully pull out the small white-drawable bar at the end of the PCI Express x16 slot when you try to install/uninstall the VGA card. Please align the VGA card to the onboard PCI Express x16 slot and press firmly down on the slot. Make sure your VGA card is locked by the small white-drawable bar.



To release an installed card, users can also press the latch on the opposite side of the drawable bar as the picture to the left shows.

1-5 I/O Back Panel Introduction



① PS/2 Keyboard and PS/2 Mouse Connector

To install a PS/2 port keyboard and mouse, plug the mouse to the upper port (green) and the keyboard to the lower port (purple).

② Parallel Port

The parallel port allows connection of a printer, scanner and other peripheral devices.

③ VGA Port

Monitor can be connected to VGA port.

④ LAN Port

The provided Internet connection is Ethernet.

⑤ USB port

Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker...etc. have a standard USB interface. Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS vendor for possible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

⑥ Line In

Devices like CD-ROM, walkman etc. can be connected to Line In jack.

⑦ Line Out (Front Speaker Out)

Connect the stereo speakers, earphone or front surround channels to this connector.

⑧ MIC In

Microphone can be connected to MIC In jack.

⑨ Center/Subwoofer Speaker Out

The default Center/Subwoofer Speaker Out jack. Center/Subwoofer speakers can be connected to Center/Subwoofer Speaker Out jack.


⑩ Surround Speaker Out (Rear Speaker Out)

The default Surround Speaker Out (Rear Speaker Out) jack. Rear surround speakers can be connected to Surround Speaker Out (Rear Speaker Out) jack.

⑪ Side Speaker Out

The default Side Speaker Out jack. Surround side speakers can be connected to Side Speaker Out jack.

1-6 Connectors Introduction




1) ATX (Power Connector)	8) SPDIF_IO
2) IDE1/ IDE2	9) WOL
3) SATA1 / SATA2	10) COMA/COMB
4) CPU_FAN / SYS_FAN	11) F_USB1 / F_USB2
5) F_PANEL	12) BAT
6) F_AUDIO	13) CLR_CMOS
7) CD_IN	14) PWR_LED

1) ATX (Power Connector) (2x12 pin ATX)

With the use of the power connector, the power supply can supply enough stable power to all the components on the motherboard. Before connecting the power connector, please make sure that all components and devices are properly installed. Align the power connector with its proper location on the motherboard and connect tightly.

Caution!


Please use a power supply that is able to handle the system voltage requirements. It is recommended that a power supply that can withstand high power consumption be used. If a power supply is used that does not provide the required power, the result can lead to an unstable system or a system that is unable to start.



Pin No.	Definition	Pin No.	Definition
1	3.3V	13	3.3V
2	3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS_ON(soft On/Off)
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	Power Good	20	-5V
9	5V SB(stand by +5V)	21	+5V
10	+12V	22	+5V
11	+12V(Only for 24-pin ATX)	23	+5V (Only for 24-pin ATX)
12	3.3V(Only for 24-pin ATX)	24	GND(Only for 24-pin ATX)


2) IDE1 / IDE2 (IDE Connector)

An IDE device connects to the computer via an IDE connector. One IDE connector can connect to one IDE cable, and the single IDE cable can then connect to two IDE devices (hard drive or optical drive). If you wish to connect two IDE devices, please set the jumper on one IDE device as Master and the other as Slave (for information on settings, please refer to the instructions located on the IDE device). Before attaching the IDE cable, please take note of the foolproof groove in the IDE connector.



3) SATA0/SATA1 (Serial ATA Connector)

Serial ATA can provide up to 150MB/s transfer rate. Please refer to the BIOS setting for the Serial ATA and install the proper driver in order to work properly.




4) CPU_FAN / SYS_FAN (Cooler Fan Power Connector)


The cooler fan power connector supplies a +12V power voltage via a 3-pin power connector and possesses a foolproof connection design.

Most coolers are designed with color-coded power connector wires. A red power connector wire indicates a positive connection and requires a +12V power voltage. The black connector wire is the ground wire (GND).

Remember to connect the CPU/system fan cable to the CPU_FAN/SYS_FAN connector to prevent CPU damage or system hanging caused by overheating.





5) F_PANEL (Front Panel Connector)



6) F_AUDIO (Front Audio Panel Connector)

This connector supports either HD (High Definition) or AC97 front panel audio module. If you wish to use the front audio function, connect the front panel audio module to this connector. Check the pin assignments carefully while you connect the front panel audio module. Incorrect connection between the module and connector will make the audio device unable to work or even damage it. For optional front panel audio module, please contact your chassis manufacturer.



HD Audio:


Pin No.	Definition
1	MIC2_L
2	GND
3	MIC2_R
4	-ACZ_DET
5	Line2_R
6	FSENSE1
7	FAUDIO_JD
8	No Pin
9	LINE2_L
10	FSENSE2

AC97 Audio:

Pin No.	Definition
1	MIC
2	GND
3	MIC Power
4	NC
5	Line Out (R)
6	NC
7	NC
8	No Pin
9	Line Out (L)
10	NC

7) CD_IN (CD IN Connector)


Connect CD-ROM or DVD-ROM audio out to the connector.




Pin No.	Definition
1	CD-L
2	GND
3	GND
4	CD-R

8) SPDIF_IO (SPDIF In/ Out)

The SPDIF output is capable of providing digital audio to external speakers or compressed AC3 data to an external Dolby Digital Decoder. Use this feature only when your stereo system has digital input function. Use SPDIF IN feature only when your device has digital output function. Be careful with the polarity of the SPDIF_IO connector. Check the pin assignment carefully while you connect the SPDIF cable. Incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional SPDIF cable, please contact your local dealer.




Pin No.	Definition
1	Power
2	No Pin
3	SPDIF
4	SPDIFI
5	GND
6	GND

9) WOL (Wake On LAN Connector)

Pin No.	Definition
1	+5V SB
2	GND
3	Signal

10) COMA / COMB


Be careful with the polarity of the COM port connectors. Check the pin assignment carefully while you connect the COM port cable, incorrect connection between the cable and connector will make the device unable to work or even damage it.



Pin No.	Definition
1	NDCDA/B-
2	NSINA/B
3	NSOUTA/B
4	NDTRA/B-
5	GND
6	NDSRA/B-
7	NRTSA/B-
8	NCTSAB-
9	NRIB-
10	No Pin



11) F_USB1 / F_USB2 (Front USB Connector)

Be careful with the polarity of the front USB connector. Check the pin assignment carefully while you connect the front USB cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional front USB cable, please contact your local dealer.



Pin No.	Definition
1	Power (5V)
2	Power (5V)
3	USB DX-
4	USB Dy-
5	USB DX+
6	USB Dy+
7	GND
8	GND
9	No Pin
10	NC

12) BAT (Battery)




- ❖ Danger of explosion if battery is incorrectly replaced.
- ❖ Replace only with the same or equivalent type recommended by the manufacturer.
- ❖ Dispose of used batteries according to the manufacturer's instructions.

If you want to erase CMOS...

1. Turn off the computer and unplug the power cord.
2. Gently take out the battery and put it aside for about one minute. (Or you can use a metal object to connect the positive and negative pins in the battery holder to make them short for five seconds.)
3. Re-install the battery.
4. Plug the power cord in and turn on the computer.

13) CLR_CMOS (Clear CMOS)

You may clear the CMOS data to its default values by this header. To clear CMOS, temporarily short the two pins. Default doesn't include the jumper to avoid improper use of this header.




Open: Normal

Short: Clear CMOS

19) PWR_LED

The PWR_LED connector is connected with the system power indicator to indicate whether the system is on/off. It will blink when the system enters suspend mode.



1

Pin No.	Definition
1	MPD+
2	MPD-
3	MPD-

Chapter 2 BIOS Setup

BIOS (Basic Input and Output System) includes a CMOS SETUP utility which allows user to configure required settings or to activate certain system features.

The CMOS SETUP saves the configuration in the CMOS SRAM of the motherboard.

When the power is turned off, the battery on the motherboard supplies the necessary power to the CMOS SRAM.

When the power is turned on, pressing the **** button during the BIOS POST (Power-On Self Test) will take you to the CMOS SETUP screen.

CONTROL KEYS

<↑><↓><←><→>	Move to select item
<Enter>	Select Item
<Esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu
<Page Up>	Increase the numeric value or make changes
<Page Down>	Decrease the numeric value or make changes
<F1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<F2>	Item Help
<F5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
<F6>	Load the Fail-Safe Defaults
<F7>	Load the Optimized Defaults
<F9>	System Information
<F10>	Save all the CMOS changes, only for Main Menu

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press **<F1>** to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press **<Esc>**.




Because BIOS flashing is potentially risky, please do it with caution and avoid inadequate operation that may result in system malfunction.

Boot up screen



The Main Menu (For example: BIOS Ver. :f3d)

Once you enter Phoenix-Award BIOS CMOS Setup Utility, the Main Menu (as figure below) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.



■ Standard CMOS Features

This setup page includes all the items in standard compatible BIOS.

■ Advanced BIOS Features

This setup page includes all the items of Phoenix - Award special enhanced features.

■ Advanced Chipset Features

This setup page includes all the items of chipset special features.

■ Integrated Peripherals

This setup page includes all onboard peripherals.

■ Power Management Setup

This setup page includes all the items of Green function features.

■ PC Health Status

This setup page is the System auto detect Temperature, voltage, fan, speed.

■ Frequency/Voltage Control

This setup page is control CPU clock and frequency ratio.

■ Load Fail-Safe Defaults

Fail-Safe Defaults indicates the value of the system parameters which the system would be in safe configuration.

■ Load Optimized Defaults

Optimized Defaults indicates the value of the system parameters which the system would be in best performance configuration.

■ Set Supervisor Password

Change, set, or disable password. It allows you to limit access to the system and Setup, or just to Setup.

■ Set User Password

Change, set, or disable password. It allows you to limit access to the system.

■ Save & Exit Setup

Save CMOS value settings to CMOS and exit setup.

■ Exit Without Saving

Abandon all CMOS value changes and exit setup.

2-1 Standard CMOS Features

Phoenix- AwardBIOS CMOS Setup Utility Standard CMOS Features		
Date (mm:dd:yy)	Tue, Mar 15 2006	Item Help
Time (hh:mm:ss)	14:42:37	Menu Level▶
► IDE Channel 0 Master	[None]	Change the day, month, year
► IDE Channel 0 Slave	[None]	<Week>
► IDE Channel 1 Master	[None]	Sun. to Sat.
► IDE Channel 1 Slave	[None]	<Month>
► IDE Channel 2 Master	[None]	Jan. to Dec.
► IDE Channel 3 Master	[None]	<Day>
Halt On	[All, But Keyboard]	1 to 31 (or maximum allowed in the month)
Base Memory	640K	<Year>
Extended Memory	511M	1999 to 2098
Total Memory	512M	
↑↓→←: Move Enter: Select F5: Previous Values		+/-PU/PD: Value F6: Fail-Safe Defaults
		F10: Save ESC: Exit F1: General Help F7: Optimized Defaults

☞ Date

The date format is <week>, <month>, <day>, <year>.

- Week The week, from Sun to Sat, determined by the BIOS and is display only
- Month The month, Jan. Through Dec.
- Day The day, from 1 to 31 (or the maximum allowed in the month)
- Year The year, from 1999 through 2098

☞ Time

The times format in <hour> <minute> <second>. The time is calculated base on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00.

☞ IDE Channel 0 Master, Slave, IDE Channel 1 Master, Slave

- IDE HDD Auto-Detection Press "Enter" to select this option for automatic device detection.
- IDE Device Setup. You can use one of three methods:
 - Auto Allows BIOS to automatically detect IDE devices during POST(default)
 - None Select this if no IDE devices are used and the system will skip the automatic detection step and allow for faster system start up.
 - Manual User can manually input the correct settings
- Access Mode Use this to set the access mode for the hard drive. The four options are: CHS/LBA/Large/Auto(default:Auto)

☞ IDE Channel 2/3 Master

- IDE HDD Auto-Detection Press "Enter" to select this option for automatic device detection.
- Extended IDE Drive SATA devices setup. You can use one of two methods:
 - Auto Allows BIOS to automatically detect SATA IDE devices during POST. (Default value)
 - None Select this if no SATA IDE devices are used and the system will skip the automatic detection step and allow for faster system start up.
- Capacity Capacity of currently installed hard disk.

» Cylinder	Number of cylinders
» Head	Number of heads
» Precomp	Write precomp
» Landing Zone	Landing zone
» Sector	Number of sectors

☞ **Halt on**

The category determines whether the computer will stop if an error is detected during power up.	
» No Errors	The system boot will not stop for any error that may be detected and you will be prompted.
» All Errors	Whenever the BIOS detects a non-fatal error the system will be stopped.
» All, But Keyboard	The system boot will not stop for a keyboard error; it will stop for all other errors. (Default value)
» All, But Diskette	The system boot will not stop for a disk error; it will stop for all other errors.
» All, But Disk/Key	The system boot will not stop for a keyboard or disk error; it will stop for all other errors.

☞ **Memory**

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

» **Base Memory**

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

The value of the base memory is typically 512K for systems with 512K memory installed on the motherboard, or 640K for systems with 640K or more memory installed on the motherboard.

» **Extended Memory**

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1 MB in the CPU's memory address map.

» **Total Memory**

This item displays the memory size that used.

2-2 Advanced BIOS Features

Phoenix- AwardBIOS CMOS Setup Utility Advanced BIOS Features		
► Hard Disk Boot Priority	[Press Enter]	Item Help
Virus Warning	[Disabled]	Menu Level▶
CPU L2 Cache ECC Checking	[Enabled]	Select Hard Disk Boot
Quick Power On Self Test	[Enabled]	Device Priority
First Boot Device	[CDROM]	
Second Boot Device	[Hard Disk]	
Third Boot Device	[LS120]	
Boot Other Device	[Enabled]	
Boot Up NumLock Status	[On]	
Typematic Rate Setting	[Disabled]	
x Typematic Rate (Chars/Sec)	6	
x Typematic Delay (Msec)	250	
Security Option	[Setup]	
HDD S.M.A.R.T. Capability	[Disabled]	
Video BIOS Shadow	[Enabled]	
Full Screen LOGO Show	[Enabled]	
Small Logo (EPA) Show	[Enabled]	
↑↓←→: Move Enter: Select +/-/PU/PD: Value F10: Save F5: Previous Values F6: Fail-Safe Defaults ESC: Exit F1: General Help F7: Optimized Defaults		

☞ Hard Disk Boot Priority

Select boot sequence for onboard(or add-on cards) SCSI, RAID, etc.

Use <↑> or <↓> to select a device, then press<+> to move it up, or <-> to move it down the list.

Press <ESC> to exit this menu.

☞ Virus Warning

If it is set to enable, the category will flash on the screen when there is any attempt to write to the boot sector or partition table of the hard disk drive. The system will halt and the warning message will appear in the mean time. You can run anti-virus program to locate the problem.

- Enabled Activate automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.
- Disabled No warning message to appear when anything attempts to access the boot sector or hard disk partition table. (Default value)

☞ CPU L2 Cache ECC Checking

- Enabled Enabled CPU L2 Cache ECC Checking.(Default Value)
- Disabled Disalbed CPU L2 Cache ECC Checking.

☞ Quick Power On Self Test

If it is set to Enable, BIOS will shorten or skip some check items during POST.

- Enabled Enabled quick POST.(Default Value)
- Disabled Normal POST.

☞ First / Second / Third Boot Device

- ▶ LS120 Select your boot device priority by LS120.
- ▶ Hard Disk Select your boot device priority by Hard Disk.
- ▶ CDROM Select your boot device priority by CDROM.
- ▶ ZIP100 Select your boot device priority by ZIP100.
- ▶ USB-FDD Select your boot device priority by USB-FDD.
- ▶ USB-ZIP Select your boot device priority by USB-ZIP.
- ▶ USB-CDROM Select your boot device priority by USB-CDROM.
- ▶ USB-HDD Select your boot device priority by USB-HDD.
- ▶ Legacy LAN Select your boot device priority by Legacy LAN.
- ▶ Disabled Disable this function.

☞ Boot Other Device

- ▶ Enabled Enabled other device boot.(Default Value)
- ▶ Disabled Disabled this function.

☞ Boot Up Num Lock Staus

- ▶ On Keypad is number keys. (Default Value)
- ▶ Off Keypad is arrow keys.

☞ Typematic Rate Setting

- ▶ Disabled Disabled typematic rate setting. (Default Value)
- ▶ Enabled Enabled typematic rate setting.

☞ Security Option

- ▶ System The system can not boot and can not access to Setup page will be denied if the correct password is not entered at the prompt.
- ▶ Setup The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt. (Default value)

☞ HDD S.M.A.R.T. Capability

S.M.A.R.T. which allows your hard disk to report any read/write errors and issue a warning when LDCM installed.

- ▶ Enabled Enabled HDD S.M.A.R.T. capability.
- ▶ Disabled Disabled HDD S.M.A.R.T. capability. (Default value)

☞ Video BIOS Shadow

It determines whether video BIOS is able to copy to RAM, however, it is optional from chipset design. Video Shadow will increase the video speed.

- ▶ Enabled Video shadow is enabled .(Default Value)
- ▶ Disabled Video shadow is desibled.

☞ Full Screen LOGO Show

- ▶ Enabled Enabled full screen logo show .(Default Value)
- ▶ Disabled Disabled full screen logo show.

☞ Small Logo(EPA) Show

- ▶ Enabled Small logo(EPA) show is enabled .(Default Value)
- ▶ Disabled Small logo(EPA) show is desibled.

2-3 Advanced Chipset Features

Phoenix- AwardBIOS CMOS Setup Utility Advanced Chipset Features		
► DRAM Clock/Drive Control	[Press Enter]	Item Help Menu Level▶
► AGP & P2P Bridge Control	[Press Enter]	
► CPU & PCI Bus Control	[Press Enter]	
Memory Hole	[Disabled]	Select Hard Disk Boot
System BIOS Cacheable	[Enabled]	Device Priority
Video RAM Cacheable	[Disabled]	
Init Display First	[PCIEx]	
xx PCI Express relative item xx		
Maximum Payload Size	[4096]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F6: Fail-Safe Defaults
		F7: Optimized Defaults

☞ DRAM Clock/Drive Control

Phoenix- AwardBIOS CMOS Setup Utility DRAM Clock/Drive Control		
Current FSB Frequency	100MHz	Item Help Menu Level▶
Current DRAM Frequency	266MHz	
DRAM Clock	[By SPD]	
DRAM Timing	[Auto By SPD]	
x SDRAM CAS Latency	[DDR/DDR 2.5 / 4]	
x Bank Interleave	Disabled	
x Precharge to Active (Trp)	4T	
x Active to Precharge (Tras)	07T	
x Active to CMD (Trd)	4T	
x REP to ACT / REF (Trfc)	20T/21T	
x ACT(0) to ACT(1) (TRRD)	3T	
IT CMD Support	[Disabled]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F6: Fail-Safe Defaults
		F7: Optimized Defaults

☞ AGP & P2P Bridge Control

Phoenix- AwardBIOS CMOS Setup Utility AGP & P2P Bridge Control		
AGP Aperture Size	[128M]	Item Help Menu Level▶
AGP3.0 Mode	[8X]	
AGP Master 1 WS Write	[Enabled]	
AGP Master 1 WS Read	[Enabled]	
VGA Share Memory Size	[64M]	
Direct Frame Buffer	[Enabled]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F6: Fail-Safe Defaults
		F7: Optimized Defaults

☞ CPU & PCI Bus Control

Phoenix- AwardBIOS CMOS Setup Utility CPU & PCI Bus Control		
PCI Master 0 WS Write	[Enabled]	Item Help Menu Level▶
PCI Delay Transaction	[Enabled]	
VLink mode selection	[By Auto]	
VLink 8X Support	[Enabled]	
VIA PWR Management	[Enabled]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F6: Fail-Safe Defaults
		F7: Optimized Defaults

☛ Current FSB Frequency	► Detect front side bus automatically.
☛ Current DRAM Frequency	► Detect DRAM fruency automatically.
☛ DRAM Clock	
► By SPD	Set DRAM Clock by SPD.(Default Value)
► 200MHz	Set DRAM Clock to 200MHz.
► 266MHz	Set DRAM Clock to 266MHz.
► 333MHz	Set DRAM Clock to 333MHz.
☛ DRAM Timing	
► Auto By SPD	Set DRAM timing auto by SPD.(Default Value)
► Manual	Set DRAM timing by manually.
☛ SDRAM CAS Latency	
► Set SDRAM CAS Latency toDDR / DDR2.5 / 4	
☛ Bank Interleave	
► Disabled	Set bank interleave to Disabled.(Default Value)
► Enabled	Set bank interleave to Enabled.
☛ Precharge to Active (Trp)	
► Set precharge to active to 4T	(Default value:4T)
☛ Active to Precharge (Tras)	
► Set Active to precharge to 07T	(Default value:07T)
☛ Active to CMD (Trcd)	
► Set Active to CMD to 4T	(Default value:4T)
☛ REP to ACT / REF(Trfc)	
► Set REP to ACT / REF to 21T	(Default value:21T)
☛ ACT(0) to ACT(1) (TRRD)	
► Set ACT(0) to ACT(1) to 3T	(Default value:3T)
☛ 1T CMD Support	
► Disabled	Disabled 1T CMD Support. (Default value)
► Enabled	Enabled 1T CMD Support.
☛ AGP Aperture Size	
► 32M	Set AGP Aperture size to 32M.
► 64M	Set AGP Aperture size to 64M.
► 128M	Set AGP Aperture size to 128M.(Default value)
► 256M	Set AGP Aperture size to 256M.
► 512M	Set AGP Aperture size to 512M.
► 1G	Set AGP Aperture size to 1G.

- ☞ **AGP 3.0 Mode**
 - ▶ 8X Set 8x to AGP AGP 3.0 mode. (Default value)
 - ▶ 4X Set 4x to AGP 3.0 mode.
- ☞ **AGP Master 1 WS Write**
 - ▶ Disabled Disabled AGP Master 1 WS write function. (Default value)
 - ▶ Enabled Enabled AGP Master 1 WS write function.
- ☞ **AGP Master 1 WS Read**
 - ▶ Disabled Disabled AGP Master 1 WS read function. (Default value)
 - ▶ Enabled Enabled AGP Master 1 WS read function.
- ☞ **VGA Share Memory Size**
 - ▶ Disabled Disabled this function.
 - ▶ 64M Set VGA share memory to 64M.(Default value)
 - ▶ 128M Set VGA share memory to 128M.
 - ▶ 256M Set VGA share memory to 256M.
- ☞ **Direct Frame Buffer**
 - ▶ Disabled Disabled direct fram buffer function.
 - ▶ Enabled Enabled direct fram buffer function. (Default value)
- ☞ **PCI Master 0 WS Write**
 - ▶ Disabled Disabled PCI Master 0 WS write.
 - ▶ Enabled Enabled PCI Master 0 WS write.(Default value)
- ☞ **PCI Delay transaction**
 - ▶ Disabled Disabled PCI delay transaction.
 - ▶ Enabled Enabled PCI delay transaction.(Default value)
- ☞ **VLink mode selection**
 - ▶ By Auto VLink mode selection by automatically. (Default value)
 - ▶ Mode 0 Set VLink mode to mode 0.
 - ▶ Mode 1 Set VLink mode to mode 1.
- ☞ **VLink 8x Support**
 - ▶ Disabled Disabled VLink 8x support.
 - ▶ Enabled Enabled VLink 8x support.(Default value)
- ☞ **VIA PWR Management**
 - ▶ Disabled Disabled VIA power management.
 - ▶ Enabled Enabled VIA power management.(Default value)
- ☞ **Memory Hole**
 - ▶ Disabled Disabled this function. (Default value)
 - ▶ 15M-16M Enabled VLink 8x support.

☛ System BIOS Cacheable

- ▶▶ Disabled Disabled System BIOS Cacheable.
- ▶▶ Enabled Enabled System BIOS Cacheable.(Default value)

☛ Video RAM Cacheable

- ▶▶ Disabled Disabled Video RAM Cacheable. (Default value)
- ▶▶ Enabled Enabled Video RAM Cacheable.

☛ Init Display First

This feature allows you to select the first initiation of the monitor display from which card when you install a PCI card and a PCI Express VGA card on the motherboard.

- ▶▶ PCIEEx Set Init display first to PCI Express VGA card.(Default value)
- ▶▶ PCI slot Set Init display first to PCI.
- ▶▶ Onboard Set Init display first to Onboard VGA.

2-4 Integrated Peripherals

Phoenix- AwardBIOS CMOS Setup Utility Integrated Peripherals		
► VIA OnChip IDE Device	[Press Enter]	Item Help
► VIA OnChip PCI Device	[Press Enter]	Menu Level▶
► SuperIO Device	[Press Enter]	
► USB Device Setting	[Press Enter]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F7: Optimized Defaults

☞ VIA OnChip IDE Device

Phoenix- AwardBIOS CMOS Setup Utility VIA OnChip IDE Device		
SATA Controller	[Enabled]	Item Help
SATA Controller Mode	[IDE]	Menu Level▶
IDE DMA transfer access	[Enabled]	
OnChip IDE Channel 0	[Enabled]	
OnChip IDE Channel 1	[Enabled]	
IDE Prefetch Mode	[Enabled]	
Primary Master PIO	[Auto]	
Primary Slave PIO	[Auto]	
Secondary Master PIO	[Auto]	
Secondary Slave PIO	[Auto]	
Primary Master UDMA	[Auto]	
Primary Slave UDMA	[Auto]	
Secondary Master UDMA	[Auto]	
Secondary Slave UDMA	[Auto]	
IDE HDD Block Mode	[Enabled]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F6: Fail-Safe Defaults
		F10: Save
		ESC: Exit
		F1: General Help
		F7: Optimized Defaults

☞ VIA OnChip PCI Device

Phoenix- AwardBIOS CMOS Setup Utility VIA OnChip IDE Device		
Azalia HDA Controller	[Auto]	Item Help
Onboard Lan Device	[Enabled]	Menu Level▶
Onboard Lan Boot ROM	[Disabled]	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F6: Fail-Safe Defaults
		F10: Save
		ESC: Exit
		F1: General Help
		F7: Optimized Defaults

☞ SuperIO Device

Phoenix- AwardBIOS CMOS Setup Utility SuperIO Device		
Onboard Serial Port1	[3F8/IRQ4]	Item Help
Onboard Serial Port2	[2F8/IRQ3]	Menu Level▶
UART Mode Select	[Normal]	
x UR2 Duplex Mode	Half	
Onboard Parallel Port	[378/IRQ7]	
Parallel Port Mode	[SPP]	
x ECP Mode Use DMA	3	
↑↓→←: Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F6: Fail-Safe Defaults
		F10: Save
		ESC: Exit
		F1: General Help
		F7: Optimized Defaults

USB Device Setting

Phoenix- AwardBIOS CMOS Setup Utility
USB Device Setting

USB 1.0 Controller	[Enabled]	Item Help
USB 2.0 Controller	[Enabled]	Menu Level▶
USB Operation Mode	[High Speed]	
USB Keyboard Function	[Enabled]	
USB Mouse Function	[Enabled]	
USB Storage Function	[Enabled]	
xxx USB Mass Storage Device Boot Setting xxx		
↑↓←→: Move Enter: Select F5: Previous Values	+/-/PU/PD: Value F10: Save F6: Fail-Safe Defaults	ESC: Exit F1: General Help F7: Optimized Defaults

SATA Controller

- ▶ Enabled Enable onboard SATA controller port. (Default value)
- ▶ Disabled Disable onboard SATA controller port.

SATA Controller Mode

- ▶ IDE Select onboard Seria ATA function as IDE.(Default value)
- ▶ RAID Select onboard Seria ATA function as RAID.

IDE DMA transfer access

- ▶ Enabled Enable IDE DMA transfer access. (Default value)
- ▶ Disabled Disable this function.

On-Chip IDE Channel0

- ▶ Enabled Enable onboard 1st channel IDE port. (Default value)
- ▶ Disabled Disable onboard 1st channel IDE port.

On-Chip IDE Channel1

- ▶ Enabled Enable onboard 2nd channel IDE port. (Default value)
- ▶ Disabled Disable onboard 2nd channel IDE port.

IDE Prefetch Mode

- ▶ Enabled Enable IDE Prefetch mode. (Default value)
- ▶ Disabled Disable IDE Prefetch mode.

Primary Master / Slave PIO

- ▶ Auto Auto detect Primary Master / Slave PIO. (Default value)
- ▶ Mode 0~4 Set Primary Master / Slave PIO from mode0~mode4.

Secondary Master / Slave PIO

- ▶ Auto Auto detect Secondary Master / Slave PIO. (Default value)
- ▶ Mode 0~4 Set Secondary Master / Slave PIO from mode0~mode4.

Primary Master / Slave UDMA

- ▶ Auto Auto detect Primary Master / Slave UDMA. (Default value)
- ▶ Disabled Disabled this function.

Secondary Master / Slave UDMA

- ▶ Auto Auto detect Secondary Master / Slave UDMA. (Default value)
- ▶ Disabled Disabled this function.

- ☞ **IDE HDD Block Mode**
 - Enabled Enable IDE HDD Block mode. (Default value)
 - Disabled Disable IDE HDD Block mode.
- ☞ **Azalia HDA Controller**
 - Auto Auto detect Azalia HDA Controller. (Default value)
 - Disabled Disable this function.
- ☞ **Onboard LAN Device**
 - Enabled Enable Onboard H/W LAN device. (Default value)
 - Disabled Disable this function.
- ☞ **On-Chip LAN BOOT ROM**

This function decide whether to invoke the boot ROM of the onboard LAN chip.

 - Enabled Enable this function.
 - Disabled Disable this function.(Default value)
- ☞ **Onboard Serial Port 1**
 - Auto BIOS will automatically setup the Serial port 1 address.
 - 3F8/IRQ4 Enable onboard Serial port 1 and address is 3F8/IRQ4. (Default value)
 - 2F8/IRQ3 Enable onboard Serial port 1 and address is 2F8/IRQ3.
 - 3E8/IRQ4 Enable onboard Serial port 1 and address is 3E8/IRQ4.
 - 2E8/IRQ3 Enable onboard Serial port 1 and address is 2E8/IRQ3.
 - Disabled Disable onboard Serial port 1.
- ☞ **Onboard Serial Port 2**
 - Auto BIOS will automatically setup the Serial port 2 address.
 - 3F8/IRQ4 Enable onboard Serial port 2 and address is 3F8/IRQ4.
 - 2F8/IRQ3 Enable onboard Serial port 2 and address is 2F8/IRQ3.(Default value)
 - 3E8/IRQ4 Enable onboard Serial port 2 and address is 3E8/IRQ4.
 - 2E8/IRQ3 Enable onboard Serial port 2 and address is 2E8/IRQ3.
 - Disabled Disable onboard Serial port 2.
- ☞ **UART Mode Select**

This item allows you to determine which Infra Red(IR) function of Onboard I/O chip.

 - Normal Set onboard I/O chip UART to normal mode. (Default value)
 - IrDA Set onboard I/O chip UART to IrDA mode.
 - ASKIR Set onboard I/O chip UART to ASKIR mode.
 - SCR Set onboard I/O chip UART to SCR mode.
- ☞ **UR2 Duplex Mode**

This feature allows you to select IR mode.

This function will available when "UART Mode Select" doesn't set at Normal.

 - Half IR Function Duplex Half. (Default value)
 - Full IR Function Duplex Full.
- ☞ **Onboard Parallel Port**
 - Disabled Disable onboard LPT port.
 - 378/IRQ7 Enable onboard LPT port and address is 378/IRQ7. (Default value)
 - 278/IRQ5 Enable onboard LPT port and address is 278/IRQ5.
 - 3BC/IRQ7 Enable onboard LPT port and address is 3BC/IRQ7.

☞ **Parallel Port Mode**

- ▶ SPP Using Parallel port as Standard Parallel Port. (Default value)
- ▶ EPP Using Parallel port as Enhanced Parallel Port.
- ▶ ECP Using Parallel port as Extended Capabilities Port.
- ▶ ECP+EPP Using Parallel port as ECP and EPP mode.

☞ **ECP Mode Use DMA**

- ▶ 3 Set ECP Mode Use DMA to 3. (Default value)
- ▶ 1 Set ECP Mode Use DMA to 1.

☞ **USB 1.0 Controller**

- ▶ Disabled Disable Universal Host controller.
- ▶ Enabled Enable Universal Host controller.(Default value)

☞ **USB 2.0 Controller**

- ▶ Disabled Disable Enhanced Host controller.
- ▶ Enabled Enable Enhanced Host controller.(Default value)

☞ **USB Operation Mode**

Auto decide USB device operation mode.

- ▶ High Speed If USB device was high speed device, then it operate on high speed mode. (Default value)
- ▶ Full/Low Speed If USB device was full/low speed device, then it operate on full/low speed mode.

☞ **USB Keyboard Function**

- ▶ Disabled Disable Legacy support of USB keyboard.
- ▶ Enabled Enable Legacy support of USB keyboard.(Default value)

☞ **USB Mouse Function**

- ▶ Disabled Disable Legacy support of USB mouse.
- ▶ Enabled Enable Legacy support of USB mouse.(Default value)

☞ **USB Storage Function**

- ▶ Disabled Disable Legacy support of USB mass storage.
- ▶ Enabled Enable Legacy support of USB mass storage.(Default value)

2-5 Power Management Setup

Phoenix- AwardBIOS CMOS Setup Utility Power Management Setup		
ACPI function	[Enabled]	Item Help Menu Level▶
ACPI Suspend Type	[S3(STR)]	
Power Management Option	[User Define]	
HDD Power Down	[Disabled]	
Suspend Mode	[Disabled]	
Video Off Option	[Suspend->Off]	
Video Off Method	[V/H SYNC+Blank]	
Modem Use IRQ	[3]	
Soft-Off by Power button	[Instant-Off]	
Run VGA BIOS if S3 Resume	[Auto]	
AC Loss Auto Restart	[Off]	
Delay Prior to Thermal	[16Min]	
HPET Support	[Enabled]	
► Wakeup Event Detect	[Press Enter]	
↑↓→← : Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F7: Optimized Defaults

☛ Wakeup Event Detect

Phoenix- AwardBIOS CMOS Setup Utility Wakeup Event Detect		
PS2KB Wakeup Select	[Hot Key]	Item Help Menu Level▶
PS2KB Wakeup key select	[Any Key]	
PS2MS Wakeup key select	[Left Botton]	
PS2 Keyboard PowerOn	[Disabled]	
PS2 Mouse Power On	[Disabled]	
Power On by PCI Card	[Disabled]	
Modem Ring Resume	[Disabled]	
RTC Alarm Resume	[Disabled]	
x Date (of Month)	0	
x Resume Time(hh:mm:ss)	0:0:0	
↑↓→← : Move	Enter: Select	+/-/PU/PD: Value
F5: Previous Values		F10: Save
		ESC: Exit
		F1: General Help
		F7: Optimized Defaults

☛ ACPI function

- Disabled Disabled ACPI function.
- Enabled Enabled ACPI function. (Default value)

☛ ACPI Suspend Type

- S1(POS) Set ACPI suspend type to S1/POS(Power On Suspend).
- S3(STR) Set ACPI suspend type to S3/STR(Suspend To RAM). (Default value)

☛ Power Management Option

- User Define For configuring our own power management features. (Default value)
- Min Saving Enabled Green function.
- Max Saving Disabled Green function.

☛ HDD Power Down

- Disabled Disabled HDD Power down function. (Default value)
- 1-15 mins Enabled HDD Power Down mode between 1 to 15 mins.

☛ Suspend Mode

- Disabled Disabled suspend mode. (Default value)
- 10 Sec -1 Hour Setup the timer to enter Suspend Mode.

- ☞ **Video Off Option**
 - ▶ Suspend -> Off Set Video off option to Off. (Default value)
 - ▶ Always On Set Video off option to On.
- ☞ **Video Off Method**
 - ▶ V/H SYNC+Blank BIOS will turn off V/H-SYNC when gets into Green mode for Green monitor power saving. (Default value)
 - ▶ Blank screen BIOS will only black monitor when gets into Green mode.
 - ▶ DPMS Support BIOS will use DPMS Standard to control VGA card.
(The Green type VGA card will turn off V/H-SYNC automatically.)
- ☞ **Modem Use IRQ**
 - ▶ NA Set Modem use IRQ to NA.
 - ▶ 3 Set Modem use IRQ to 3.(Default value)
 - ▶ 4 Set Modem use IRQ to 4.
 - ▶ 5 Set Modem use IRQ to 5.
 - ▶ 7 Set Modem use IRQ to 7.
 - ▶ 9 Set Modem use IRQ to 9.
 - ▶ 10 Set Modem use IRQ to 10.
 - ▶ 11 Set Modem use IRQ to 11.
- ☞ **Soft-Off by Power button**
 - ▶ Instant-off Press power button then Power off instantly. (Default value)
 - ▶ Delay 4 Sec Press power button 4 seconds to Power off. Enter suspend if button is pressed less than 4 seconds.
- ☞ **Run VGA BIOS if S3 Resume**
 - ▶ Auto Set run VGA BIOS if S3 resume automatically. (Default value)
 - ▶ Yes Enabled run VGA BIOS if S3 resume.
 - ▶ No Disabled this function.
- ☞ **AC Loss Auto Restart**
 - ▶ Off Disabled this function. (Default value)
 - ▶ On Set AC Loss auto restart.
 - ▶ Former-Sts Set AC Loss to former-Sts.
- ☞ **Delay Prior to Thermal**
 - ▶ 4 Min Set 4 min for delay prior to thermal.
 - ▶ 8 Min Set 8 min for delay prior to thermal.
 - ▶ 16 Min Set 16 min for delay prior to thermal. (Default value)
 - ▶ 32 Min Set 32 min for delay prior to thermal.
- ☞ **HPET Support** (Note)
 - ▶ Disabled Disable this function.
 - ▶ Enabled Enable support for High Precision Event Timer (HPET) function. (Default value)

(Note) Supported on Vista operating system only.

- ☞ **PS2KB Wakeup Select**
 - Hot Key Set Hot key to wakeup PS/2 Keyboard.
- ☞ **PS2KB Wakeup Key select**

When set at Password, you can set the password here.

 - Enter Input password (from 1 to 8 characters) and press Enter to set the Keyboard Power On password.
- ☞ **PS2MS Wakeup key Select**
 - Left Botton Double click on PS/2 mouse left button to power on the system. (Default value)
 - Right Botton Double click on PS/2 mouse right button to power on the system.
- ☞ **PS2 Keyboard PowerOn**
 - Disabled Disable this function. (Default value)
 - Enabled Enable PS2 Keyboard PowerOn.
- ☞ **PS2 Mouse PowerOn**
 - Disabled Disable this function. (Default value)
 - Enabled Enable PS2 Mouse PowerOn.
- ☞ **Power On by PCI Card**
 - Disabled Disable this function. (Default value)
 - Enabled Enable power on by PCI card.
- ☞ **Modem Ring Resume**
 - Disabled Disable this function. (Default value)
 - Enabled Enable modem ring resume.
- ☞ **RTC Alarm Resume**

You can set "Resume by Alarm" item to enabled and key in Date/Time to power on system.

 - Disabled Disable this function. (Default value)
 - Enabled Enable alarm function to POWER ON system.

If Power-On by Alarm is Enabled.

 - Day of Month Alarm : Everyday, 1~31
 - Time (hh: mm: ss) Alarm : (0~23) : (0~59) : (0~59)

2-6 PC Health Status

Phoenix- AwardBIOS CMOS Setup Utility	
PC Health Status	
	Item Help
VCORE	1.10V
DDRII Voltage	1.85V
VCC3	3.36V
VCC	5.00V
+12V	12.06V
System Temperature	34°C
CPU Temperature	48°C
CPU FAN Speed	3183 RPM
SYSTEM FAN Speed	0 RPM

↑↓→←: Move Enter: Select +/-/PU/PD: Value F10: Save
 F5: Previous Values F6: Fail-Safe Defaults ESC: Exit F1: General Help
 F7: Optimized Defaults

- ☞ **Current DDRII Voltage(V) / Vcore / VCC3 / +12V**
 - Detect system's voltage status automatically.
- ☞ **Current System / CPU Temperature**
 - Detect System / CPU temperature automatically.
- ☞ **Current CPU / SYSTEM FAN Speed (RPM)**
 - Detect CPU / System fan speed status automatically.

2-7 Frequency / Voltage Control

Phoenix- AwardBIOS CMOS Setup Utility		
Frequency / Voltage Control		
		Item Help
Auto Detect PCI Clk	[Enabled] [+/-0.20%] [Default]	Menu Level▶
Spread Spectrum		
CPU / PCIEX / AGP / PCI		
↑↓→←: Move F5: Previous Values	+/-PU/PD: Value F6: Fail-Safe Defaults	F10: Save ESC: Exit F1: General Help F7: Optimized Defaults



CAUTION Incorrect using these features may cause your system broken. For power end-user use only.

☞ Auto Detect PCI Clk

- ▶ Disabled Disabled auto detect PCI clock.
- ▶ Enabled Enabled atuo detect PCI clock.(Default value)


☞ Spread Spectrum

- ▶ Disabled Disable CPU Spread Spectrum.
- ▶ +/-0.20% Set Spread Spectrum to +/-0.20%.(Default value)
- ▶ +/-0.25% Set Spread Spectrum to 0.25%.
- ▶ +/-0.375% Set Spread Spectrum to 0.375%.
- ▶ +/-0.5% Set Spread Spectrum to 0.5%.

☞ CPU / PCIEX / AGP / PCI


- ▶ Default Auto detect CPU / PCIEX / AGP / PCI .(Default value)
- ▶ 100/100/66/33 MHz CPU 100MHz / PCIEX 100MHz / AGP 66MHz / PCI 33MHz

2-8 Load Fail-Safe Defaults




Fail-Safe defaults contain the most appropriate values of the system parameters that allow minimum system performance.

2-9 Load Optimized Defaults



Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

2-10 Set Supervisor/User Password



When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password, up to eight characters, and press <Enter>. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message "PASSWORD DISABLED" will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.


The BIOS Setup program allows you to specify two separate passwords:

SUPERVISOR PASSWORD and a USER PASSWORD. When disabled, anyone may access all BIOS Setup program function. When enabled, the Supervisor password is required for entering the BIOS Setup program and having full configuration fields, the User password is required to access only basic items.

If you select "System" at "Password Check" in Advance BIOS Features Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu.

If you select "Setup" at "Password Check" in Advance BIOS Features Menu, you will be prompted only when you try to enter Setup.


2-11 Save & Exit Setup



Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS.

Type "N" will return to Setup Utility.

2-12 Exit Without Saving



Type "Y" will quit the Setup Utility without saving to RTC CMOS.

Type "N" will return to Setup Utility.

